



280zx Injector Cooling Fan Wiring Diagram Correction

The FSM wiring diagrams are wrong for both Z31 and 280zx



SEF736B

Howler Monkey is Correct Here
Back of connector as if plugged into unit on left.



Temp. Switch supplies negative when car is hot enough for fan operation. When temp switch is active, fan will operate only after ignition is shut off.

Some people will just ground temp. switch lead to ensure fan operates for 17 minutes every time car is shut off.