

PART NO.	DESCRIPTION	QTY	UNIT PKG FOR BIST	APPLIED MODEL	APPLIED DATE	
					FROM	UP TO
08530-51642	SCREW-TAPPING M5	4	50			
08530-51620	SCREW-TAPPING M5	4	50			
76952-P7100	PLATE-KICKING,RH (BLACK)	1	1	2 SEATER		08/81
76950-P7100	PLATE-KICKING,RH (BLACK)	1	1	2 SEATER		08/81
76950-P9400	PLATE-KICKING,RH (SILVER)	1	1	2S	09/81	
76952-P7101	PLATE-KICKING,RH (BROWN)	1	1	2 SEATER		06/80
76950-P7101	PLATE-KICKING,RH (BROWN)	1	1	2 SEATER		06/80
76950-P8001	PLATE-KICKING,RH (BROWN)	1	1	2S	07/80	
76952-P7102	PLATE-KICKING,RH (RED)	1	1	2 SEATER		
76950-P7102	PLATE-KICKING,RH (RED)	1	1	2 SEATER		
76952-P7103	PLATE-KICKING,RH (BLUE)	1	1	2 SEATER		
76950-P7103	PLATE-KICKING,RH (BLUE)	1	1	2 SEATER		
76952-P7160	PLATE-KICKING,RH (BLACK)	1	1	2+2 SEATER		08/81
76950-P7160	PLATE-KICKING,RH (BLACK)	1	1	2+2 SEATER (EXC.EUR T,ASR T)		08/81
76950-P9460	PLATE-KICKING,RH (SILVER)	1	1	4S (EXC.EUR T,ASR T)	09/81	
76952-P7161	PLATE-KICKING,RH (BROWN)	1	1	2+2 SEATER		06/80
76950-P7161	PLATE-KICKING,RH (BROWN)	1	1	2+2 SEATER (EXC.EUR T,ASR T)		06/80
76950-P8061	PLATE-KICKING,RH (BROWN)	1	1	4S(EXC.EUR T, ASR T)	07/80	
76952-P7162	PLATE-KICKING,RH (RED)	1	1	2+2 SEATER		
76950-P7162	PLATE-KICKING,RH (RED)	1	1	2+2 SEATER (EXC.EUR T,ASR T)		

PART NO.	DESCRIPTION	QTY	UNIT PKG FOR BEST	APPLIED MODEL	APPLIED DATE	
					FROM	UP TO
76952-P7163	PLATE-KICKING,RH (BLUE)	1	1	2+2 SEATER		
76950-P7163	PLATE-KICKING,RH (BLUE)	1	1	2+2 SEATER (EXC.EUR T,ASR T)		
76950-P8760	PLATE-KICKING,RH (BLACK G01-1)	1	1	T(2+2 SEATER) (EUR,ASR)	1079	0881
76950-P8860	PLATE-KICKING,RH (SILVER G50-1)	1	1	T(4S)(EUR,ASR)	0981	
76950-P8761	PLATE-KICKING,RH (BROWN C18-1)	1	1	T(2+2 SEATER) (EUR,ASR)	1079	0680
76950-P8661	PLATE-KICKING,RH (BROWN C67-1)	1	1	T(4S)(EUR,ASR)	0780	
76950-P8762	PLATE-KICKING,RH (RED A05-1)	1	1	T(2+2 SEATER) (EUR,ASR)	1079	
76950-P8763	PLATE-KICKING,RH (BLUE B21-1)	1	1	T(2+2 SEATER) (EUR,ASR)	1079	
76953-P7100	PLATE-KICKING,LH (BLACK)	1	1	2 SEATER		0679
76951-P7100	PLATE-KICKING,LH (BLACK)	1	1	2 SEATER		0679
76951-P7110	PLATE-KICKING,LH (BLACK G01-1)	1	1	2 SEATER	0779	0881
76951-P9400	PLATE-KICKING,LH (SILVER G50-1)	1	1	2S	0981	
76953-P7101	PLATE-KICKING,LH (BROWN)	1	1	2 SEATER		0679
76951-P7101	PLATE-KICKING,LH (BROWN)	1	1	2 SEATER		0679
76951-P7111	PLATE-KICKING,LH (BROWN C18-1)	1	1	2 SEATER	0779	0680
76951-P8001	PLATE-KICKING,LH (BROWN C67-1)	1	1	2S	0780	
76953-P7102	PLATE-KICKING,LH (RED)	1	1	2 SEATER		0679

PART NO.	DESCRIPTION	QTY	UNIT PKG FOR DIST	APPLIED MODEL	APPLIED DATE	
					FROM	UP TO
76951-P7102	PLATE-KICKING,LH (RED)	1	1	2 SEATER		0679
76951-P7112	PLATE-KICKING,LH (RED A05-1)	1	1	2 SEATER	0779	
76953-P7103	PLATE-KICKING,LH (BLUE)	1	1	2 SEATER		0679
76951-P7103	PLATE-KICKING,LH (BLUE)	1	1	2 SEATER		0679
76951-P7113	PLATE-KICKING,LH (BLUE B21-1)	1		2 SEATER	0779	
76953-P7160	PLATE-KICKING,LH (BLACK)	1	1	2+2 SEATER		0679
76951-P7160	PLATE-KICKING,LH (BLACK)	1	1	2+2 SEATER		0679
76951-P7170	PLATE-KICKING,LH (BLACK G01-1)	1	1	2+2 SEATER (EXC.EUR T,ASR T)	0779	0881
76951-P9460	PLATE-KICKING,LH (SILVER G50-1)	1	1	45 (EXC.EUR T,ASR T)	0981	
76953-P7161	PLATE-KICKING,LH (BROWN)	1	1	2+2 SEATER		0679
76951-P7161	PLATE-KICKING,LH (BROWN)	1	1	2+2 SEATER		0679
76951-P7171	PLATE-KICKING,LH (BROWN C18-1)	1	1	2+2 SEATER (EXC.EUR T,ASR T)	0779	0680
76951-P8061	PLATE-KICKING,LH (BROWN C67-1)	1	1	45(EXC.EUR T, ASR T)	0780	
76953-P7162	PLATE-KICKING,LH (RED)	1	1	2+2 SEATER		0679
76951-P7162	PLATE-KICKING,LH (RED)	1	1	2+2 SEATER		0679
76951-P7172	PLATE-KICKING,LH (RED A05-1)	1	1	2+2 SEATER (EXC.EUR T,ASR T)	0779	
76953-P7163	PLATE-KICKING,LH (BLUE)	1	1	2+2 SEATER		0679
76951-P7163	PLATE-KICKING,LH (BLUE)	1	1	2+2 SEATER		0679
76951-P7173	PLATE-KICKING,LH (BLUE B21-1)	1	1	2+2 SEATER (EXC.EUR T,ASR T)	0779	